## GUIDELINE OF X PURGE FOR INJECTION MACHINE

Recommended quantity of **Seurge** according to the clamping force.

| Clamping Force (Ton) | Recommended Quantity (kg) |  |  |  |
|----------------------|---------------------------|--|--|--|
| 100                  | 1.5                       |  |  |  |
| 200                  | 3.0                       |  |  |  |
| 550                  | 6.0                       |  |  |  |
| 750                  | 15.0                      |  |  |  |
| 1200                 | 65.0                      |  |  |  |

### GUIDELINE OF X PURGE FOR BLOW MOLDING, BLOWN FILM AND EXTRUSION MACHINE

Recommended quantity of **Durge** according to screw diameter.

| Screw Diameter (mm) | Recommended Quantity (kg) |  |  |  |
|---------------------|---------------------------|--|--|--|
| 65                  | 11                        |  |  |  |
| 90                  | 17                        |  |  |  |
| 100                 | 20                        |  |  |  |
| 130                 | 30                        |  |  |  |

Remark: Blending with resin at ratio 50:50 is recommend for the best cleaning. The actual amount required may depending on equipment and material.



### Special Tips

To enhance a cleaning performance, and black spot removal. Soaking within machine 5-10 min is recommended.

### Restriction on usage

Fume may occur at high processing temperature. It can cause temporary slight eye and nose irritation but it is unlikely to cause significant skin irritation.



### Personal protection

Safety glass with side shield should be worn. Mask or respirator for organic vapor is recommended when the ventilation in working area is not sufficient.

Any inquiry about cleaning other plastic machines and shut-down/start-up nachines, please contact our technical team for further information.



### PTT Global Chemical Public Company Limited


555/1 Energy Complex, Building A, 14<sup>th</sup> - 18<sup>th</sup> Floor, Vibhavadi Rangsit Road, Chatuchak, Chatuchak, Bangkok 10900 Thailand.







Data as of 1July 2022



# **PURGING COMPOUND**



is high efficiency ready-to-use purging compound which provides fast and effective color, material change and contaminant removal in the machine without disassemble. machine downtime and/or maximize productivity. This product is designed for cleaning various types of the machines i.e., injection molding machines, blow molding machine, blown film machine, sheet casting machine, sheet/profile extrusion machine.















2











| X PURGE GRADE |            | Recommend temperatural and matterial |                                   | Type of<br>Machine |              | Feature   |                                                |
|---------------|------------|--------------------------------------|-----------------------------------|--------------------|--------------|-----------|------------------------------------------------|
| 8             | 140-240 °C | 200-240 °C                           | 240-290 °C                        | 290-340 °C         | Injection    | Extrusion | reature                                        |
| GX168         | PVC, TI    | PE, PE                               |                                   |                    | $\checkmark$ | <b>~</b>  | General<br>Grade                               |
| EX20T         |            |                                      | , ABS, PC/ABS,<br>Γ, PA6 +GF      | PA66 + GF<br>,LCP  | <b>~</b>     | ✓         | High Heat<br>Stability                         |
| PX319<br>NEW  |            |                                      | 2S , ABS, PC/ABS,<br>A66, PA6 +GF |                    | <b>√</b>     |           | Low smok<br>and Smel<br>Superior<br>Efficiency |



# **"FAST AND EFFECTIVE PURGING MATERIAL"**





# CLEANING OR CHANGEOVER PROCEDURES:

## **Step I. Preparing**

- Clean hopper & Empty the barrel by running machine until the material is used up.
- Adjust screw speed by 30-50% of normal condition.
- Remove screen pack (if, machine is equipped).

## Step II. Cleaning by X PURGE

- Pour **Dever**, into the hopper.
- Purge continuously until machine is completely clean.

## Step III. Flushing the X PURGE

- Run machine until Stores is used up.
- Flushing out the remaining **Second** by using the next desired material.

## Step IV. Starting next production

- Adjust processing condition to normal & 5 Install screen pack (if, machine is equipped).
  - Start next production.